

Commonly used items and amps needed to run them

Item	Amps
Display lights (3-60 watt bulbs)	1.5 – 2 amps
Consumer size crock pot	6-7 amps
Commercial size crock pot/warmer	10-15 amps
Small (dorm size) refrigerator	5-6 amps
Full size refrigerator	10 amps
Microwave	15 amps (typically)
Electric Grill	10 amps
Television	2.5-3 amps (plasma TVs are higher, confirm wattage)
DVD or VCR	1 amp
Laptop Computer	5 amps max

To find the most accurate amps use the formula wattage/voltage (120V) for each item you need to have electricity. Add the total of ALL items to be used to find the amount of amps you need for your booth. If you have questions, please call Margaret Henderson at (505) 271-9050 or email at Margaret@fiery-foods.com.